

Ball Machine Guidelines & Troubleshooting



About 150 balls are provided for the ball machine use on court #1, as well as a ball mower and tennis tube(s), free of charge for any member. We would greatly appreciate if you could follow these simple guidelines.

- Do not remove any balls for personal use on a different court.
- Do not add any additional balls to the machine. If you would like to donate balls, please bring them to a clubhouse employee.
- Retrieve any balls that might have wandered outside the fenced perimeter of the court.
- Treat the ball retrieving equipment with care. (e.g. remove balls from against the fence before using mower)
- Make sure that all children are supervised and not using ball machine as a batting practice.

La Madrona Athletic Club is happy to bring you the ball machine free of charge and would like to continue to do so. Any failure to follow these guidelines may revoke your ball machine privileges.

Troubleshooting:

1. Verify that the power cord is well connected at both ends.
2. Always make sure the power is turned off before trying the next 2 steps.
3. Make sure the controller is set at bypass and not remote.
4. Look inside the front of ball machine and dislodge any balls stuck in the wheels system.
5. If machine is still not working, report immediately to a clubhouse employee.

We hope you enjoy your ball machine practice.

Thank you for your cooperation.